



Transom Saver - Installation Instructions -

- 1) Determine mounting application - either roller style or bolt on - and attach correct end piece.
- 2) Trim the motor to the desired position for trailering and determine length for transom saver.
- 3) Adjust the length of the transom saver by telescoping the unit to the desired length. Add extension piece if necessary and tighten all bolts.
- 4) Place transom saver on trailer roller or bolt on bracket and trim engine down until snug. **CAUTION: OVER TRIMMING COULD RESULT IN DAMAGE TO LOWER UNIT OR TRANSMO SAYER.**
- 5) Wrap rubber strap around the lower unit securing each end to the transom saver head.

